

DN SERIES 1U55 CHOP MANUAL

	<u>TABLE OF CONTENTS</u>	<u>PAGE</u>
1.	INSTALLATION	1
2.	FUNCTIONS	2 -4
3.	TROUBLE SHOOTING GUIDE	5
4.	OPERATING PROCEDURE. SOLUTION GUIDE	6 -7
5.	CASSETTE ERROR. SOLUTION GUIDE	8
6.	ELECTRONIC, MECHANICAL PARTS	9 -20
7.	ELECTRONIC CONNECTIONS	21-26
8.	MONITOR	27-30
9.	POWER SUPPLY	31-33
10.	P.C. BOARD SCHEMATICS	34-37

INSTALLATION

1. Position cabinet at desired location.
2. Adjust leg levelers so cabinet is balanced correctly.
3. Plug the machine into a 120 volt outlet.
4. Open the front service door.
 - a. If the game was pre-installed at the factory, proceed to line 9.
5. Place cassette tape in the cassette deck. See Figure 1, game package installation.
6. Install key module. See Figure 2, game package installation.
7. Adjust dipswitches to desired settings. See Figure 3, and please refer to the game package dipswitch setting sheet.
8. Install game top flashing.
9. Turn power switch on, located at the front of the machine.
10. Allow 2-3 minutes for the game to load the memory.
11. The game is now ready for operation.*

* If the game has any irregularities, refer to the system trouble shooting guide on the next pages.





Figure 1

Figure 2

Figure 3

1. FUNCTIONS

THE THREE PCB'S DO NOT FUNCTION AS A GAME UNLESS TAPE PROGRAM IS LOADED TO THE PCB'S.



STRUCTURE Fig. 1

2. INDIVIDUAL FUNCTION OF EACH BLOCK

DSP 8

- 1) CONTROL CPU AND ITS RELATED CIRCUIT
- 2) COLOR SIGNAL GENERATOR AND CONTROL
- 3) STANDARD PATTERN GENERATOR AND TIMING SIGNAL GENERATOR
 - * CPU CLOCK
 - * STROBE SIGNAL
 - * DYNAMIC RAM TIMING SIGNAL
- 4) CRT TIMING SIGNAL GENERATOR
 - * HORIZONTAL
 - * VERTICAL
 - * SYNCHRONIZE
- 5) DISPLAY CONTROL
 - * MISSILE GENERATOR AND CONTROL
 - * MIXMODE GENERATOR AND CONTROL
 - * MAIN GRAPHIC GENERATOR AND CONTROL

RMS 8

- 1) DYNAMIC MEMORY (48 K BYTE)
 - * PROGRAM
 - * DISPLAY
- 2) SOUND
 - * CPU
 - * ROM/RAM
 - * SOUND CHIP
 - * MIXING
 - * COMMUNICATION WITH MAIN CPU

3) RESET SIGNAL GENERATOR

4) DIP SWITCH READING

5) BOOTSTRAP ROM

BIO 8

1) CONTROL PANEL SWITCH INPUT READING

2) COIN SWITCH ACTIVATION READING AND COIN COUNTER DRIVE

3) NMI GENERATION FROM SERVICE/COIN SWITCH ACTIVATION

4) VOLUME INPUT AD CONVERSION

5) BACK DISPLAY CONTROL

* READING/WRITING PUNCTION FROM CPU TO MEMORY

* HEAD LIGHT MODE

* DISPLAY HORIZONTAL/VERTICAL SHIFT

6) CASSETTE DECK INTERFACE

CASSETTE DECK

1) GAME PROGRAM LOADING


DC POWER SOURCE

1) SWITCHING REGULATOR

+5V (REGULATED)	6A
+12V (")	1A
+13V (UNREGULATED)	2A
-5V (REGULATED)	0.1A

IF REGULATED +12V, 3A COMBINATION IS USED IT ALLOWS
+13V UNREGULATED POWER USE.

DECO CASSETTE SYSTEM
TROUBLE SHOOTING GUIDE



SEE NEXT PAGE FOR
SOLUTIONS

OPERATING PROCEDURES, SOLUTION GUIDE

SOLUTIONS

#1 CHECK DIP SWITCH SETTINGS

SETTINGS MUST ALWAYS BE

DIP SW I	5.OFF	6.OFF	
DIP SW II	6.ON	7.OFF	8.OFF

#2 CHECK KEY MODULE CONNECTION

#3 CHECK FUSES

#4 CHECK AC INPUT TO SWITCHING REGULATOR 100V.AC AND DC OUTPUT +5, -5, +12

#5 ASSURE POWER IS CONNECTED TO CARD RACK

#6 CHECK MONITOR POWER CONNECTOR FOR 100V.AC

#7 CHECK MONITOR FUSES

#8 CHECK VIDEO CONNECTOR

#9 EXCHANGE PCB'S

D E C O
CASSETTE
SYSTEM

WAIT UNTIL COUNTER
BELOW READS 000 THEN
GAME START

— BLUE BACKGROUND —

FIGURE #1

D E C O
CASSETTE
SYSTEM

1 2 0

FIGURE #2

D E C O
CASSETTE
SYSTEM

CASSETTE ERROR!

← REFER TO ERROR GUIDE
#59


FIGURE #3

CASSETTE ERROR GUIDE


ERROR CODE	SOLUTIONS
01	1,8,9,3
02	3,4,5
03	3,4,5
04	3,4,5
32	2,3
33	5
52	8,9,4
58	3,4,5
59	6,7,8

CASSETTE ERROR SOLUTIONS


- #1 CHECK THE TAPE AND MODULE GAME NAME TO INSURE THEY ARE PROPERLY MATCHED.
- #2 CLEAN THE TAPE DECK HEAD WITH ALCOHOL AND COTTON SWAB
- #3 CHANGE THE CASSETTE TAPE
- #4 CHANGE THE CASSETTE DECK
- #5 IF THE ERROR PERSISTS CHANGE THE BIO-8 BOARD
- #6 CHECK THE TAPE DECK CONNECTOR
- #7 CHECK THE KEY MODULE CONNECTOR
- #8 CHECK THE TAPE TO INSURE SIDE "A" IS FACING UP
- #9 CHECK THE TAPE TO INSURE THAT THE TAPE IS ON THE SPOOL OPPOSITE THE CAPITOL "A", IF NOT ADVANCE THE TAPE TO THE CORRECT SPOOL WITH A SCREWDRIVER




	CABINET 1-US-5-A	Q'TY
1	PRELIM CAB ASSY	1
2	BEZEL HOUSING	1
3	CARD CAGE BOARD	1
4	BACK DOOR ASSY	1
5	FRONT PANEL DOOR ASSY	1
6	#8 x 5/8 PH SMS PHIL	1



	CABINET 1-US-5-B	Q'TY
1	PRELIM CAB ASSY	1
2	BEZEL HOUSING	1
3	CARD CAGE BOARD	1
4	BACK DOOR ASSY	1
5	FRONT PANEL DOOR ASSY	1
6	#8 x 5/8 PH SMS PHIL	1




1	FACIAL PANEL	1
2	FILTER	1
3	ESCUTCHEON	1
4	MASKING PANEL	1
5	LIGHT BULB	2
6	LIGHT BRACKET	2
7	25¢ SEAL	2
8	SEAL FRAME	2
9	COIN SELECTOR	2
10	COIN FUNNEL	2
11	SWITCH BRACKET	1
12	POWER SWITCH	1
13	MAIN FUSE	1
14	DEMAGNETIZER SWITCH	1
15	PCB MOUNTING SCREWS	3
16	LEVELER	2
17	PCB MOUNTING BOARD	1




1	SPEAKER & LIGHT HOUSING ASS'Y	1
2	GOLD T MOLD	2
3	TOP FLASH	1
4	CONTROL PANEL ASS'Y	1
5	FRONT DOOR PANEL	1
6	COIN SELECTOR DOOR FRAME	1
7	SELECTOR DOOR	1
8	SELECTOR DOOR HINGE	1
9	SELECTOR DOOR LOCK	1
10	CASH BOX DOOR HINGE	1
11	CASH BOX LOCK	1
12	CASH BOX DOOR	1
13	CASH BOX DOOR FRAME	1
14	CASH BOX	1
15	COIN COUNTER	1
16	COIN COUNTER CIRCUIT BOARD	1
17	BACK DOOR	1
18	BACK DOOR LOCK	1

CONTROL PANEL



	CONTROL PANEL ASSEMBLY FOR US-5	Q'TY
1	CONTROL PANEL CHASSIS	1
2	PLAYER I & II BUTTONS (YELLOW)	2
3	SHOOT BUTTON-I (RED)	1
4	SHOOT BUTTON-II (BLUE)	1
5	CONTROL PANEL OVERLAY -A WITH 2 SHOOT BUTTON HOLE -B WITH 1 SHOOT BUTTON HOLE	1
6	CONTROL LEVER ASS'Y	1
7	WING NUT	2
8	SPRING WASHER	2
9	LARGE WASHER	2
10	CONTROL PANEL INSTALLATION BRACKET	2
11	OVERLAY PLASTIC FASTNER	6


NO	DESCRIPTION	REF.
1	KNOB	P-50913-0
2	SHAFT	P-51080-0
3	METAL BASE	LS-7-1
4	COVER	LS-7-4
5	BEARING	LS-7-5
6	NYLON BASE	LS-7-3
7	SPRING STOPPER	LS-7-6
8	TP SCREW	
9	SPRING	LS-7-15
10	BRASS STOPPER	LS-7-16




SANWA CONTROL LEVER
(DLS-5)

11	E RING ϕ 6	P-51-81-0
12	GUIDE COLLAR	
13	PW 4	
14	M4	
15	TP SCREW	
16	LEVER GUIDE	4 WAY
17	TP SCREW	
18	SWITCH BRACKET	
19	MICRO SWITCH	
20	TP SCREW	
21	TP SCREW	


DATA EAST
DRAWING
NO. K-50774-0






	SPEAKER & LIGHT HOUSING ASSEMBLY	UK-01111
1	SPEAKER & LIGHT HOUSING CHASSIS	1
2	FL BULB	1
3	FOAM CUSHION	1
4	LIGHT FIXTURE	1
5	FL STARTER	1
6	SPEAKER	1
7	SCREWS	4

P.C.B. ASSEMBLY




NOS	DESCRIPTION	PARTS-NOS.	Q'TY/SET
1	CN SUPPORT	K-50216-3	1
2	SIDE PLATE (R)	K-50603-0	1
3	SIDE PLATE (L)	K-50604-0	1
4	SIDE PLATE		
5	SUPPORT	P-50935-1	2
6	GUIDE RAIL	50-1030	8
7	WING BOLT		4
8	SW4		4
9	PW4		4
10	TP3x8		14
11	TP3x8		8
12	TP3x12		8
13	B108	DE-0098	1
14	DSP8	DE-0096	1
15	RMS8	DE-0097	1
16	BUS10	DE-0109	1

CASSETTE DECK ASSEMBLY




NOS	DESCRIPTION	PARTS NOS	Q'TY/SET
1	CASSETTE BRACKET (A)	G-50177-1	1
2	CASSETTE DOOR	K-50575-1	1
3	CASSETTE BRACKET (B)	P-50947-0	1
4	RUBBER CUSHION (A)	P-50949-0	2
5	RUBBER CUSHION (B)	P-50950-0	2
6	CASSETTE BRACKET	K-50141-2	1
7	RUBBER SHEET	P-50769-0	1
8	CASSETTE DECK	MD-3A	1
9	SCREW TP3x8	6	
10	SCREW M3x6	4	
11	SCREW M2.6x12	4	
12	NUT M3	4	
13	SCREW 3P3x8	2	


圖面號	圖樣名稱
1	
2	
3	
4	
5	
6	
7	
8	
9	
10	
11	
12	




SCHEMATIC INSTRUMENT
K-10451-7

圖面號	圖樣名稱	規格	備註
1			
2			
3			
4			
5			
6			
7			
8			
9			
10			
11			
12			






PC1 RMS8 CN1



CABLE C V-200236-1 To Speaker

1		
2		
3	SPEAKER- (GND)	BLACK
4	SPEAKER+	WHITE


2. PC2 DSP8 CN1



CABLE D V-200235-1 To RGB Monitor

1	TV.B	BLUE
2	TV.G	GREEN
3	TV.R	RED
4	TV.GND	BLACK
5		
6	SYNC	WHITE

BUS 10 CN2




CABLE H V-200240-1 To Power Supply

1	+12V	ORANGE
* 2	+5V	RED
3	+13V	PINK
* 4	GND	BLACK
* 5	GND	BLACK
6	-5V	BLUE
* 7	+5V	RED
8		

*2 & 7 connected internally
on BUS 10


*4 & 5 connected internally
on BUS 10



CABLE F V-200242-1 to Player Controls & Coin Selectors


BLACK & WHITE	A1	GND	B1	GND	BLACK & WHITE
	A2	1p(R)	B2	1p(L)	ORANGE
RED	A3	1p(U)	B3	1p(D)	ORANGE
RED	A4	1p SHOOT 1	B4	1p SHOOT 2	BLUE
YELLOW	A5		B5		
RED	A6	2p(R)	B6	2p(L)	ORANGE
YELLOW	A7	2p(U)	B7	2p(D)	GREEN
VIOLET	A8	2p SHOOT 1	B8	2p SHOOT 2	BLUE
	A9		B9		
	A10		B10		
	A11		B11	1p	BROWN
BLUE & WHITE	A12	2p	B12		
	A13	-	B13		
WHITE	A14	COIN SW 2	B14		
GREEN	A15	COIN SW 1	B15		
BLACK & WHITE	A16	GND	B16	-	
BROWN	A17	BLOCKER 1	B17	BLOCKER 2	RED
	A18		B18		
	A19		B19		
WHITE	A20	COUNTER 2	B20	COUNTER 1	VIOLET
	A21	-	B21	-	
	A22	-	B22		
	A23		B23		
	A24		B24		
	A25		B25		

20110D BLOCK DIAGRAM




20INCH MONITOR 201100
K-10435

CRT. D W/B 20110D





001-003.0107-00612 pg 1815
0107-0108 28A 1015
0107-0109 111555




SA/MA
20 INCH MONITOR 2010E
K-10435


2/01/10










記号	担当	年月日	改訂編	機、材質
材質	處理	公差	名稱	ELCO SNS-50



料號		規格		名稱	
承認	備註	供應	備註	規格	備註
				SANKEN SWS-608	
				SWITCHING REGULATOR	







年月日	改訂	制版	符号	部品、图面符号	名	仕様	封頁
材質	處理	公差			名稱	RMS-8	
基準	基準	基準	基準	基準	圖號	G-10024-0	
内裏	米	17.00	17.00	17.00			